

# SC-F500 Series

# **General Information**

CMP0204-01 EN

#### **Copyrights and Trademarks**

# **Copyrights and Trademarks**

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson printer. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON, EPSON EXCEED YOUR VISION, EXCEED YOUR VISION, and their logos are registered trademarks or trademarks of Seiko Epson Corporation.

Microsoft®, Windows®, and Windows Vista® are registered trademarks of Microsoft Corporation.

Mac, macOS, OS X, Bonjour, and Safari are trademarks of Apple Inc., registered in the U.S. and other countries.

Chrome <sup>™</sup>, Chrome OS <sup>™</sup>, and Android <sup>™</sup> are trademarks of Google Inc.

Intel® is a registered trademark of Intel Corporation.

Adobe and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

HP-GL/2® and HP RTL® are registered trademarks of Hewlett-Packard Corporation.

The SuperSpeed USB Trident Logo is a registered trademark of USB Implementers Forum, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

 $\ensuremath{\texttt{@}}$  2019 Seiko Epson Corporation. All rights reserved.

#### Contents

# Contents

Copyrights and Trademark	S
--------------------------	---

Notes on Manuals
Meaning of Symbols
Illustrations
Product Model Descriptions 4
Manual Organization
Important Safety Instructions
Notes on Installing
Notes on Handling
Notes on the Power Supply
Notes on Consumables
Other Notes
System Requirements
Printer Driver
Web Config
Specifications Table
For European users
Where To Get Help
Technical Support Web Site
Contacting Epson Support
Before Contacting Epson
Help for Users in North America 16
Help for Users in Europe
Help for Users in Taiwan 16
Help for Users in Australia/New Zealand 17
Help for Users in Singapore
Help for Users in Thailand
Help for Users in Vietnam
Help for Users in Indonesia
Help for Users in Hong Kong
Help for Users in Malaysia
Help for Users in India
Help for Users in the Philippines 20

#### **Notes on Manuals**

# **Notes on Manuals**

# **Meaning of Symbols**

Marning:	Warnings must be followed to avoid serious bodily injury.
Caution:	Cautions must be followed to avoid bodily injury.
[] Important:	Important must be followed to avoid damage to this product.
Note:	Notes contain useful or additional information on the operation of this product.
	Indicates related reference content.

Illustrations

The illustrations may differ slightly from the model you are using. Please be aware of this when using the manuals.

# Product Model Descriptions

Some models described in this manual may not be sold in your country or region.

# **Manual Organization**

The manuals for the product are organized as shown below.

You can view the PDF manuals using Adobe Acrobat Reader or Preview (Mac).

Setup Guide (booklet)	Provides information on how to setup the printer after unpacking it from the box. Make sure you read this manual to perform operations safely.
Operator's Guide (PDF)	Explains the necessary basic operations and maintenance for daily use.
General Information (this manual)	Provides important safety instructions, printer specifications and contact details.
Online Manual	
User's Guide (PDF)	Provides overall information and instructions on using the printer and on solving problems.

# **Important Safety Instructions**

Read all of these instructions before using the printer. Also be sure to follow all warnings and instructions marked on the printer.

# **Notes on Installing**

#### **Warning**

#### Do not obstruct the vents on the product.

If the vents are obstructed, the internal temperature could rise and cause a fire. Do not cover the printer with a cloth or install it in a location with poor ventilation. Make sure you secure sufficient space for the installation as described in the manual.

#### **A** Caution

Do not install or store the printer in an unstable location or a location subject to vibrations from other equipment.

The printer could fall or tip over and cause an injury.

Do not install the printer in locations subject to oily smoke and dust, or in locations subject to humidity or where it could easily get wet.

An electric shock or fire could occur.

Do not tilt the product more than 10 degrees forward, back, left, or right while moving it.

Failure to observe this precaution could result in the printer falling over, causing accidents.

Because the product is heavy, it should not be carried by one person.

Make sure the product is carried by two people or more when unpacking or moving it. See the following for details on the product's weight.

Before assembling the product, make sure you clear away the packaging sheets, packing materials, and supplied items from the installation area.

If you slip or trip on these items, it could cause an injury.

Make sure you use the correct posture when lifting the product.

Lifting using the wrong posture could cause an injury.

When lifting the product, make sure you lift at the locations indicated in the manual.

If you lift holding other parts, the printer may fall, catching your fingers and causing an injury. See the following for details on lifting the product.

#### **A** Caution

When placing the product on a stand with casters (wheels), make sure you secure the casters before you perform the work so that they do not move.

If the stand moves while you are performing the work, it could cause an injury.

Do not try to move the stand\* while the casters (wheels) are secured.

Failure to observe this precaution could result in the printer falling over, causing accidents.

When moving the printer while it is on the stand\*, avoid locations with steps or uneven flooring.

Failure to observe this precaution could result in the printer falling over, causing accidents.

# **Notes on Handling**

#### **Marning**

Do not use the printer in locations with volatile substances such as alcohol or thinner, or near naked flames.

An electric shock or fire could occur.

Do not use the printer if it is giving off smoke or if you notice any abnormal odors or noises.

An electric shock or fire could occur. If any abnormalities occur, turn off the power and unplug the power cable immediately, and then contact your dealer or Epson Support.

Never try to repair the printer yourself as this is extremely dangerous.

Do not use the printer in an environment where flammable gas or explosive gas may exist. Do not use sprays that contain flammable gas inside or near the product.

A fire could occur.

Only route the cables as indicated in the manual.

A fire could occur. This could also cause damage to connected devices.

Do not insert or drop any metallic or flammable items into the openings on the printer.

An electric shock or fire could occur.

Do not touch any areas inside the printer except for those indicated in the manual.

An electric shock or burn could occur.

Do not disassemble anything except when indicated to do so in the manual.

If the LCD for the control panel is damaged, be careful of any leaking liquid crystal.

Provide first aid under any of the following conditions.

- ☐ If liquid adheres to your skin, immediately wipe it off and then wash the area using large volumes of soapy water.
- ☐ If any liquid gets in your eyes, flush them with clean water for at least 15 minutes, and consult a physician immediately.
- ☐ If liquid enters your mouth, consult a physician immediately.

<sup>\*</sup>Optional item.

#### **Warning**

If any foreign objects or liquid such as water enters the printer, stop using it immediately.

An electric shock or fire could occur. Turn off the power and unplug the power cable immediately, and then contact your dealer or Epson Support.

During lightning storms, do not touch the product and the power cable that are connected to the power outlet.

An electric shock could occur.

#### **A** Caution

Do not sit on the product or place any heavy objects on the product.

Be careful with small children. The printer could fall or tip over and cause an injury.

Do not put your fingers near the paper eject roller section when the printer is on or when it is printing.

If your fingers are caught in the paper eject roller, an injury could occur. Only handle the paper after it has been ejected completely.

When transporting or storing the product, be sure that it is level: do not tilt it at an angle or place it upside down.

Ink could leak.

Store the cutter in a location out of the reach of children.

The cutter's blade could cause an injury. Pay careful attention when replacing the cutter.

When connecting cables or optional accessories, make sure they are installed in the correct direction and that you follow the procedures exactly.

A fire or an injury could occur. Connect the cables or optional accessories correctly by following the instructions in the manual.

When moving the product, make sure it is turned off, the power cable is unplugged from the outlet, and all connecting cables have been removed.

If cables are damaged, an electric shock or fire could occur.

Except when moving the stand, make sure the two casters (wheels) at the front of the stand\* are secured.

If they are not secured, an accident could occur.

Make sure to grip the flanges of the spindle when loading a roll paper.

If you hold and load the roll paper by gripping the other parts, your hand or finger may get injured.

When transporting this product, attach the transportation caps and then secure the ink tank caps.

Ink could leak.

<sup>\*</sup>Optional item.

# **Notes on the Power Supply**

# Warning Use only the type of power source indicated on the printer's label. An electric shock or fire could occur. Do not use the plug if any foreign objects such as dust have adhered to the plug. An electric shock or fire could occur. Do not use any other power cables except for the cable supplied with the printer. Also, do not use the power cable supplied with the printer for any other devices. An electric shock or fire could occur. Do not use the power cable if it is damaged. An electric shock or fire could occur. If the power cable is damaged, contact Epson Support. Note the following points to avoid damaging the power cable. ☐ Do not modify the power cable. Do not place anything heavy on the power cable. Do not bend, twist, or pull forcefully on the power cable. ☐ Do not route the power cable near heaters. Do not connect too many cables to the power outlet for the power cable. The temperature could rise and cause a fire. Connect the power cable directly to an outlet for domestic use. Do not insert or unplug the plug with wet hands. An electric shock could occur. Make sure the blades on the plug are inserted completely into the power outlet. An electric shock or fire could occur. Unplug the plug regularly and clean between the blades and around the base of the blades. If the plug is plugged in for an extended period of time, dust collects around the base of the blades and a short circuit or fire could be a collect of the blades and a short circuit or fire could be a collect of the blades and a short circuit or fire could be a collect of the blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a short circuit or fire could be a collect or fire blades and a collect or fire blades are fire blades and a collect or fire blaoccur. When unplugging the plug, grip the plug itself; do not pull the power cable. If the cable is damaged or the plug is deformed, an electric shock or fire could occur.

# (Caution

If you are not going to use the printer for an extended period, unplug the printer for safety reasons.

# **Notes on Consumables**

Be sure to read the Product Safety Data Sheet before use. You can download Product Safety Data Sheets from the Epson Web site.

<b>A</b> Caution	
Do not shake the ink bottles or maintenance box too hard.	
Ink or waste liquid may leak from the ink bottles if you shake them too hard.	
Do not disassemble the ink bottles or the maintenance box.	
If it is disassembled, ink or waste liquid could get in your eyes or adhere to your skin.	
If ink contacts your skin or enters your eyes or mouth, immediately take the following actions.	
☐ If ink adheres to your skin, immediately wash it off using soap and water.	
If ink enters your eyes, rinse immediately with water. Failure to observe this precaution could result in bloodshot eyes or mild inflammation. If you notice any problems or abnormalities at all, consult a physician immediately.	
☐ If ink enters your mouth, consult a physician immediately.	
Store the ink bottles and the maintenance box in a location out of reach of children.	
Note the following points when refilling ink.	
☐ Firmly tighten the caps of the ink bottles. Otherwise, ink could leak.	
☐ Make sure ink does not leak when pouring ink into the inlet. Otherwise, ink may splash.	
You may not be able to clean off ink that splashes onto clothes or belongings.	
Do not drink the ink.	
Do not rub the edges of the printing paper with your hand.	
The edges of the paper are thin and sharp and could cause an injury.	

# **Other Notes**

Be sure your power cable meets relevant safety standards of the area where you plan to use it.
Do not put your hand inside this product or touch the printer head during printing.
Do not put your hand inside this product or touch the white flat cable during printing.

#### **System Requirements**

# **System Requirements**

Software for this printer can be used in the following environments. (As of June, 2019) Supported OS and other elements may change.

For the latest information, see the Epson Web site.

# **Printer Driver**

#### Windows

Operating system	Windows 10 / Windows 10 x64 Windows 8.1 / Windows 8.1 x64 Windows 8 / Windows 8 x64 Windows 7 / Windows 7 x64 Windows Vista / Windows Vista x64 Windows XP / Windows XP x64 Windows Server 2019 Windows Server 2016 Windows Server 2012 R2 Windows Server 2012 Windows Server 2008 R2 Windows Server 2008 Windows Server 2008 Windows Server 2003 R2 Windows Server 2003 SP2 or later
CPU	Intel Core2 Duo 3.05 GHz or more
Available memory space	1 GB or more
Hard disk (Available volume to install)	32 GB or more
Display resolution	WXGA (1280×800) or better
Connection method with the printer*	USB, Ethernet, or Wi-Fi

<sup>\*</sup> For details on the connection methods (interface specifications), see the following.

#### Mac

Operating system	Mac OS X v10.6.8 or later
СРИ	Intel Core2 Duo 3.05 GHz or more
Available memory space	4 GB or more
Hard disk (Available volume to install)	32 GB or more
Display resolution	WXGA+ (1440×900) or better

#### **System Requirements**

Connection method with the printer*	USB, Ethernet, or Wi-Fi
-------------------------------------	-------------------------

<sup>\*</sup> For details on the connection methods (interface specifications), see the following.

#### **System Requirements**

# **Web Config**

Web Config is an application that runs in a web browser on a computer or smart device connected to the same network with the printer.

△ Administrator's Guide

#### Windows

Browser	Internet Explorer 11, Microsoft Edge, Firefox*1, Chrome*1
Connection method with the printer*2	Ethernet or Wi-Fi

<sup>\*1</sup> Use the latest version.

#### Mac

Browser	Safari <sup>*1</sup> , Firefox <sup>*1</sup> , Chrome <sup>*1</sup>
Connection method with the printer*2	Ethernet or Wi-Fi

<sup>\*1</sup> Use the latest version.

#### **Smart device**

Operating system	iOS*1
Connection method with the printer*2	Wi-Fi

<sup>\*1</sup> Use the latest version.

 ${\cal L}$  "Specifications Table" on page 13

<sup>\*2</sup> See the following for details on the network interfaces.


<sup>\*2</sup> See the following for details on the network interfaces.

<sup>\*2</sup> See the following for details on the network interfaces.

#### **Specifications Table**

# **Specifications Table**

Printer Specifications		
Printing method	PrecisionCore inkjet technology	
Nozzle configura- tion	800 nozzles x 4 colors ((Black, Cyan, Magenta, Yellow)	
Resolution (maxi- mum)	2400 × 1200 dpi	
Control code	ESC/P raster (undisclosed command), HP-GL/2, HP RTL	
Built-in memory	1.0 GB	
Rated voltage	AC100-240 V	
Rated frequency	50/60 Hz	
Rated current	1.4 A	
Power consumption		
Printing	Approx. 22 W	
Ready mode	Approx. 8 W	
Sleep mode	Approx. 1.6 W	
Power off	Approx. 0.2 W	
Temperature		
Printing	10 to 35 °C (15 to 25°C is recommended)	
In storage (Before unpacking)	-20 to 60 °C (Within 120 hours at 60 °C, within a month at 40 °C)	
In storage (After unpacking)	-10 to 40 $^{\circ}$ C (Within a month at 40 $^{\circ}$ C)	
Humidity		
Printing	20 to 80% (40 to 60% is recommended. without condensation)	
In storage	5 to 85% (without condensation)	



	Dimensions (Width x Depth x Height)			
Printing		970 x 577 x 245 mm (When the optional stand is installed*1: 970 x 980 x 928 mm)		
	Storage	970 x 577 x 245 mm (When the optional stand is installed: 970 x 695 x 928 mm)		
	Weight <sup>*2</sup>	Approx. 29 kg (When the optional stand is installed: approx. 40 kg)		

- \*1 With the paper basket open
- \*2 Not including the ink

### 🚺 Important:

Use the printer at an altitude of 2000 m or less.

Interface Specifications		
USB port for a computer	SuperSpeed USB	
Ethernet <sup>*1</sup> Standards	IEEE802.3u (100BASE-TX) IEEE802.3ab (1000BASE-T) IEEE802.3az (Energy Efficient Ethernet)*2	
Wi-Fi		

#### **Specifications Table**

Interface Specifications				
Standards	IEEE802.11b/g/n*3			
Frequency Range	2.4 GHz			
Coordination Modes	Infrastructure Wi-Fi Direct (Simple AP)*4			
Wireless Securities	WEP (64/128bit) WPA-PSK (TKIP) WPA2-PSK (AES)*5 WPA3-SAE WPA2-Enterprise (AES) WPA3-Enterprise*6			
Network Printing Protocols/Func- tions* <sup>7</sup>	EpsonNet Print (Windows) Standard TCP/IP (Windows) WSD Printing (Windows) Bonjour Printing (Mac) IPP Printing (Mac) Printing from FTP client			
Security Protocols	SSL/TLS (HTTPS Server/Client, IPPS) IEEE802.1X IPsec/IP Filtering SMTPS (STARTTLS, SSL/TLS) SNMPv3			

- \*1 Use a category 5 or higher STP (Shielded twisted pair) cable.
- \*2 The connected device should comply with IEEE802.3az standards.
- \*3 IEEE802.11n is only available for the HT20.
- \*4 Not supported for IEEE 802.11b.
- \*5 Complies with WPA2 standards with support for WPA/WPA2 Personal.
- \*6 192-bit security is not supported.
- \*7 EpsonNet Print supports IPv4 only. The others support both IPv4 and IPv6.



#### / Warning:

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing

Ink Specifications	
Туре	Dedicated ink bottle
Dye sublimation ink	Black, Cyan, Magenta, Yellow

Ink Specifications		
Print quality guar- antee expiry	25 days (from the day the ink tank was refilled with an ink bottle)	
Storage temperature		
Uninstalled	-20 to 40°C (Within four days at -20 °C, within a month at 40 °C)	
Transporting	-20 to 60°C (Within four days at -20°C, within a month at 40°C, within 72 hours at 60°C)	
Capacity	140 ml	



#### Important:

The ink freezes if left in the ink bottles at below -20 °C for a long time. If it does freeze, leave it at room temperature (25°C) for at least two hours.

# For European users

#### **Radio Equipment Information**

This product intentionally emit radio wave described as follows.

- (a) frequency band in which the radio equipment operates; 2.4 to 2.4835 GHz
- (b) maximum radio-frequency power transmitted in thefrequency band in which the radio equipment operates;20dBm (eirp power)

# Where To Get Help

# **Technical Support Web Site**

Epson's Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your product documentation. If you have a Web browser and can connect to the Internet, access the site at:

#### http://support.epson.net/

If you need the latest drivers, FAQs, manuals, or other downloadables, access the site at:

#### http://www.epson.com

Then, select the support section of your local Epson Web site.

# **Contacting Epson Support**

# **Before Contacting Epson**

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact Epson support services for assistance. If Epson support for your area is not listed below, contact the dealer where you purchased your product.

Epson support will be able to help you much more quickly if you give them the following information:

- ☐ Product serial number (The serial number label is usually on the back of the product.)
- □ Product model
- ☐ Product software version (Click **About**, **Version Info**, or similar button in the product software.)
- Brand and model of your computer
- ☐ Your computer operating system name and version
- ☐ Names and versions of the software applications you normally use with your product

### **Help for Users in North America**

Epson provides the technical support services listed below.

#### **Internet Support**

Visit Epson's support website at http://epson.com/ support and select your product for solutions to common problems. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

#### **Speak to a Support Representative**

Dial: (562) 276-1300 (U.S.), or (905) 709-9475 (Canada), 6 am to 6 pm, Pacific Time, Monday through Friday. Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Before you call Epson for support, please have the following information ready:

	D	14	
_	Pro	auct	name

	l Proc	luct	serial	num	ber
--	--------	------	--------	-----	-----

Proof of purchase (such as a store receipt) and date
of purchase

_	I Com	puter	config	uration

_	D	C .1	1.1
_	Description	of the	problem

#### Note:

For help using any other software on your system, see the documentation for that software for technical support information.

# **Purchase Supplies and Accessories**

You can purchase genuine Epson ink cartridges, ribbon cartridges, paper, and accessories from an Epson authorized reseller. To find the nearest reseller, call 800-GO-EPSON (800-463-7766). Or you can purchase online at http://www.epsonstore.com (U.S. sales) or http://www.epson.ca (Canadian sales).

## **Help for Users in Europe**

Check your **Pan-European Warranty Document** for information on how to contact Epson support.

# **Help for Users in Taiwan**

Contacts for information, support, and services are:

# World Wide Web (http://www.epson.com.tw)

Information on product specifications, drivers for download, and products enquiry are available.

# Epson HelpDesk (Phone: +0800212873)

Our HelpDesk team can help you with the following over the phone:

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

#### **Repair service center:**

Fax number	Address
02-23417070	No.20, Beiping E. Rd., Zhongzheng Dist., Taipei City 100, Taiwan
02-27495955	1F., No.16, Sec. 5, Nanjing E. Rd., Songshan Dist., Taipei City 105, Taiwan
02-32340699	No.1, Ln. 359, Sec. 2, Zhongshan Rd., Zhonghe City, Taipei County 235, Taiwan
039-600969	No.342-1, Guangrong Rd., Luodong Township, Yilan County 265, Taiwan
038-312977	No.87, Guolian 2nd Rd., Hualien City, Hualien County 970, Taiwan
03-4396589	5F., No.2, Nandong Rd., Pingzhen City, Taoyuan County 32455, Taiwan (R.O.C.)
	number  02-23417070  02-27495955  02-32340699  039-600969  038-312977

Telephone number	Fax number	Address
03-5325077	03-5320092	1F., No.9, Ln. 379, Sec. 1, Jingguo Rd., North Dist., Hsinchu City 300, Taiwan
04-23011502	04-23011503	3F., No.30, Dahe Rd., West Dist., Taichung City 40341, Taiwan (R.O.C.)
04-23805000	04-23806000	No.530, Sec. 4, Henan Rd., Nantun Dist., Taichung City 408, Taiwan
05-2784222	05-2784555	No.463, Zhongxiao Rd., East Dist., Chiayi City 600, Taiwan
06-2221666	06-2112555	No.141, Gongyuan N. Rd., North Dist., Tainan City 704, Taiwan
07-5520918	07-5540926	1F., No.337, Minghua Rd., Gushan Dist., Kaohsiung City 804, Taiwan
07-3222445	07-3218085	No.51, Shandong St., Sanmin Dist., Kaohsiung City 807, Taiwan
08-7344771	08-7344802	1F., No.113, Shengli Rd., Pingtung City, Pingtung County 900, Taiwan

# Help for Users in Australia/New Zealand

Epson Australia/New Zealand wishes to provide you with a high level of customer service. In addition to your product documentation, we provide the following sources for obtaining information:

#### **Your Dealer**

Don't forget that your dealer can often help identify and resolve problems. The dealer should always be the first call for advise on problems; they can often solve problems quickly and easily as well as give advise on the next step to take.

#### **Internet URL**

Australia http://www.epson.com.au

New Zealand http://www.epson.co.nz

Access the Epson Australia/New Zealand World Wide Web pages.

The site provides a download area for drivers, Epson contact points, new product information and technical support (e-mail).

#### **Epson Helpdesk**

Epson Helpdesk is provided as a final backup to make sure our clients have access to advice. Operators on the Helpdesk can aid you in installing, configuring and operating your Epson product. Our Pre-sales Helpdesk staff can provide literature on new Epson products and advise where the nearest dealer or service agent is located. Many types of queries are answered here.

The Helpdesk numbers are:

Australia Phone: 1300 361 054 FAX: (02) 8899 3789

New Zealand Phone: 0800 237 766

We encourage you to have all the relevant information on hand when you ring. The more information you prepare, the faster we can help solve the problem. This information includes your Epson product documentation, type of computer, operating system, application programs, and any information you feel is required.

# **Help for Users in Singapore**

Sources of information, support, and services available from Epson Singapore are:

#### **World Wide Web**

(http://www.epson.com.sg)

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), Sales Enquiries, and Technical Support via e-mail are available.

# Epson HelpDesk (Phone: (65) 6586 3111)

Our HelpDesk team can help you with the following over the phone:

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

## Help for Users in Thailand

Contacts for information, support, and services are:

#### **World Wide Web**

(http://www.epson.co.th)

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and e-mail are available.

# Epson Hotline (Phone: (66)2685-9899)

Our Hotline team can help you with the following over the phone:

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

## **Help for Users in Vietnam**

Contacts for information, support, and services are:

Epson Hotline (Phone): 84-8-823-9239

Service Center: 80 Truong Dinh Street,

District 1, Hochiminh City

Vietnam

# Help for Users in Indonesia

Contacts for information, support, and services are:

#### **World Wide Web**

(http://www.epson.co.id)

- ☐ Information on product specifications, drivers for download
- ☐ Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

#### **Epson Hotline**

- ☐ Sales enquiries and product information
- ☐ Technical support

Phone (62) 21-572 4350

Fax (62) 21-572 4357

#### **Epson Service Center**

Jakarta Mangga Dua Mall 3rd floor No 3A/B

Jl. Arteri Mangga Dua,

Jakarta

Phone/Fax: (62) 21-62301104

Bandung Lippo Center 8th floor

Jl. Gatot Subroto No.2

Bandung

Phone/Fax: (62) 22-7303766

Surabaya Hitech Mall lt IIB No. 12

Jl. Kusuma Bangsa 116 – 118

Surabaya

Phone: (62) 31-5355035 Fax: (62)31-5477837

Yogyakarta Hotel Natour Garuda

Jl. Malioboro No. 60

Yogyakarta

Phone: (62) 274-565478

Medan Wisma HSBC 4th floor

Jl. Diponegoro No. 11

Medan

Phone/Fax: (62) 61-4516173

Makassar MTC Karebosi Lt. Ill Kav. P7-8

JI. Ahmad Yani No.49

Makassar

Phone: (62)411-350147/411-350148

## **Help for Users in Hong Kong**

To obtain technical support as well as other after-sales services, users are welcome to contact Epson Hong Kong Limited.

### **Internet Home Page**

Epson Hong Kong has established a local home page in both Chinese and English on the Internet to provide users with the following information:

- Product information
- ☐ Answers to Frequently Asked Questions (FAQs)
- ☐ Latest versions of Epson product drivers

Users can access our World Wide Web home page at:

http://www.epson.com.hk

## **Technical Support Hotline**

You can also contact our technical staff at the following telephone and fax numbers:

Phone: (852) 2827-8911

Fax: (852) 2827-4383

# **Help for Users in Malaysia**

Contacts for information, support, and services are:

#### **World Wide Web**

(http://www.epson.com.my)

- ☐ Information on product specifications, drivers for download
- ☐ Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

#### **Epson Trading (M) Sdn. Bhd.**

Head Office.

Phone: 603-56288288

Fax: 603-56288388/399

#### **Epson Helpdesk**

☐ Sales enquiries and product information (Infoline)

Phone: 603-56288222

☐ Enquiries on repair services & warranty, product usage and technical support (Techline)

Phone: 603-56288333

# **Help for Users in India**

Contacts for information, support, and services are:

#### **World Wide Web**

(http://www.epson.co.in)

Information on product specifications, drivers for download, and products enquiry are available.

## **Epson India Head Office - Bangalore**

Phone: 080-30515000

Fax: 30515005

## **Epson India Regional Offices:**

Location	Telephone number	Fax number
Mumbai	022-28261515 / 16/17	022-28257287
Delhi	011-30615000	011-30615005
Chennai	044-30277500	044-30277575
Kolkata	033-22831589 / 90	033-22831591
Hyderabad	040-66331738/39	040-66328633

Location	Telephone number	Fax number
Cochin	0484-2357950	0484-2357950
Coimbatore	0422-2380002	NA
Pune	020-30286000 / 30286001 /30286002	020-30286000
Ahmedabad	079-26407176 / 77	079-26407347

☐ Inquiries on repair service and warranty

#### Helpline

For Service, Product info or to order a cartridge - 18004250011 (9AM - 9PM) - This is a Toll-free number.

For Service (CDMA & Mobile Users) - 3900 1600 (9AM - 6PM) Prefix local STD code

# **Help for Users in the Philippines**

To obtain technical support as well as other after sales services, users are welcome to contact the Epson Philippines Corporation at the telephone and fax numbers and e-mail address below:

Trunk Line: (63-2) 706 2609

Fax: (63-2) 706 2665

Helpdesk (63-2) 706 2625

Direct Line:

E-mail: epchelpdesk@epc.epson.com.ph

#### World Wide Web

(http://www.epson.com.ph)

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and E-mail Inquiries are available.

Toll-Free No. 1800-1069-EPSON(37766)

Our Hotline team can help you with the following over the phone:

☐ Sales inquiries and product information

☐ Product usage questions or problems