MDF Wood Products



MDF WOOD PRODUCTS - UVLED Printing

HD105FW | HD104FW | HD103FW | HD101FW | HD106FW | HD107FW | HD109FW | HD110FW | HD112FW | HD113FW | HD113FW | HD115FW | HD115FW | HD125FW | HD126FW | HD127W | HD129I | HD130FW | HD131FW | HD132FW | HD133FW | HD150W | HD151FW | HD154FW | HD156FW | HD157FW | HD158FW | HD159FW | HD160FW | HD161FW | HD162FW | HD163FW









GENERAL UVLED PRINT PROCESS

Recommended Equipment & Accessories

- UVLED printer
- Clean Towel
- Glass cleaner
- Optional: Tacky mat

Recommended Settings	
Ink Type	Hard Ink
UV Lamp	100%

General UVLED Printing Instructions

- Place the product on the printer bed. If necessary, use of a jig or tacky mat is recommended to help hold the product.
- Focus the print head to the surface of the product.
- Place the printer into print-ready position and send the job to the printer.
- When finished, remove the product from the printer bed.
- Allow 24 hours for the UV ink to fully cure.

Note: Products are not recommended for use with food after the image has been printed.

Tips and Tricks

- To help with artwork placement, utilize the product template for this item, found on the item's product page on jpplus.com/..
- Create or employ a jig to help hold the product for easier positioning and faster changeovers when UV printing high volumes.

Troubleshooting

- The image scratches off easily.
 - Printing white only, or printing white with color will usually not have as high of an adhesion strength as printing color-only, even with the use of adhesion promoter.
 - o Allow 24 hours for the UV ink to fully cure and to achieve maximum adhesion strength.
 - o Increase the UV lamp setting if it is not already set to 100%.
 - Some materials used on components of some products may not be well-suited for high adhesion strength on UVLED print technology.
- The image is fuzzy, has fuzzy edges, or appears blurry.
 - o The print head may be slightly out of focus with the surface of the product.
 - o If printing on a curved product surface, the curvature of the product may be out of focus of the print head.
 - Run a nozzle check on the printer to ensure that all print nozzles are firing properly during printing.

Templates and Images

• Visit jpplus.com to find the product page for this item. The product template may be found under the Tech Docs and Downloads area of the page.

To order more of this product, see similar products and much more, please visit jpplus.com.

For additional product support and troubleshooting, please contact JPPlus Advanced Support Team:

- Phone: 419-500-4877
- Email: ast@jpplus.com
- Schedule an appointment: https://jpplusadvancedsupport.setmore.com/