Scott Wall Bracket Instructions

STOP AT TOP OF SLOT

Screws

Vertical Line

1) Slide two spring clips into slot from end, and position one at each end.

2) The end of 1/8" sign blank to be inserted in holder, should be beveled both sides to a point which will start easily into clips

3) Push Plastic sign into bracket and tap to seat both clips: Align top of sign with top of bracket.

4) Install two #8 flat head screws in wall approx. 1 " apart and plumb. Let head protrude enough to enter slot yet hold bracket snug to wall.

5) Slide bracket down and over screws.