

## SUBLIMATABLE FABRIC PORTFOLIO

SG340

### Settings

- **Time:** 70 seconds
- **Temperature:** 390 °F
- **Pressure:** Heavy

### Fabrication Process

- Place sacrificial paper on press bed.
- Clean the surface with a lint roller to remove any dust or fibers.
- Place transfer onto the fabric. (secure with heat tape if needed)
- Open & lay flat on press bed w/ board under the front. (The side you are sublimating.) This is to ensure even pressure across the front cover.
- Place another sheet of sacrificial paper over the transfer.
- Press the item



### Notes:

- To avoid line indentations from paper edges, use a transfer sheet larger than the substrate.
- Paper may stick to the fabric, peel away slowly.