TECH TIP

RECTANGULAR CHEESE BOARD WITH CERAMIC TILE INSERT

CB1838

Settings

• Time: 2 - 3 minutes Temperature: 400° F

Pressure: Moderate



Fabrication Process

- Affix the transfer to the tile using heat tape.
- Place sacrificial paper on the heat press bed.
- Set the insert on the bed with the transfer paper side up.
- Press the insert. After pressing, allow ample time to cool.
- Place tile insert in cutting board frame.

Note:

Insert will be extremely hot. Use of gloves or a cloth is recommended for removal of finished product from press.

