

ChromaLuxe Natural Wood Panels

Sublimation Instructions

When sublimating Natural Wood Prints it is important to keep the bleed on your transfer to a minimum in order to reduce the appearance of dyes on the sides. Suggested bleed is 0.1" on all four sides with transfer taped to the back of the panel.

Temperature - 400°

Time - 1:30 to 2:30 depending on size

NOTE:

- Make sure your product is face up on the heat press.
- Do not apply the heat tape to the edge of the wood panel as it will leave a mark.

ChromaLuxe Natural Wood Prints provide a vibrancy and durability that make it the best photo on wood in the market. These are made with a maple veneer with a low gloss ChromaLuxe coating and have pre-drilled keyholes on the back that make them ready to hang out of the box.

