

FAUX BURLAP DRAWSTRING BAG – FBDB05, FBDB10, FBDB15

Settings

- **Time:** 45 seconds
- **Temperature:** 419° F
- **Pressure:** Moderate / Heavy

Fabrication Process

- Place the bag on top of the transfer sheet (image face up). Secure bag to transfer sheet with heat tape.
- Place blowout paper on heat press platen.
- Place bag with attached transfer sheet on top of blowout paper. Transfer sheet should be on top.
- Adjust press pressure to med/heavy. Close press.
- Press for recommended time. When finished, open press and remove the bag. Remove transfer sheet and discard.
- Repeat steps for the second side of the bag.

Note: It is recommended to sublimates one side of the bag at a time. Print the artwork onto the sublimation transfer sheet. Leave enough space around the artwork for the transfer sheet to overlap the bag on all edges. For edge to edge printing, increase the image size so that the image overlaps all edges of the bag by at least 1/8". Utilize the product template to ensure full coverage.

