

## VAPOR SOLAR SHIRTS

Johnson Plastics Plus recommends using the Vapor Foam kit (SUBFK1, SUBFK2) when sublimating the Vapor Shirts to achieve better quality sublimation results and allow higher quality image transfer. For detailed instructions on the use of the Vapor Foam kit, please refer to the Vapor Foam Instructions PDF found on the Vapor Foam product page on JPPlus.com.

### Supplies

- Vapor Foam Kit (SUBFK1, SUBFK2) recommended for best results!
- Standard Flat Heat Press
- Teflon Sheet(s) or Blowout Paper
- Heat Tape

### Settings

- **Time:** 35 seconds
- **Temperature:** 370° F
- **Pressure:** Light to Moderate

### Fabrication Process

- Refer to Vapor Foam Instructions located at: <https://www.jpplus.com/vapor-foam-kit>

**Note:** These recommendations are offered in conjunction with manufacturer's settings. Due to variations in equipment and shop conditions, minor adjustments may be needed to achieve optimal results.