

SQUARE COMPACT MIRROR – SG310-EA

Settings

- **Time:** 45 seconds
- **Temperature:** 375 - 390° F
- **Pressure:** Moderate

Fabrication Process

- Remove the protective film from the aluminum insert.
- Affix the transfer to the insert using heat tape.
- Place sacrificial paper on the heat press bed.
- Set the insert on the bed with the transfer paper side up.
- Place additional sheet of sacrificial paper over the insert.
- Press the insert.



Note:

Insert will be extremely hot. Use of gloves or a cloth is recommended for removal of finished insert from press. | Due to variances in equipment and conditions, minor setting adjustments may be needed to achieve optimal results.