- + The OKI Pro9541WT currently ships directly from the factory with the following User Type media profiles installed for some of the latest textile media. Media Settings can be located within the printer driver under the Paper/Quality tab, Tray Selection, Media pull down menu.
- + If you have a customer that is using one of the listed media, it is recommended that they select the appropriate User Type to print.

USER TYPES

- 1. Forever® Laser Dark (No Cut) LowTemp
- 2. Forever® Laser Light (No Cut)
- 3. Neenah® Image Clip® Laser Dark
- 4. Neenah® Image Clip® Laser Light
- 5. Shockline FC TOPDARKNEW
- 6. Shockline FC TOPCUT2013
- 7. TMT WoW7.8
- 8. TMT T.One
- 9. (future use)
- 10. (future use)



